

Index

A

- AAMA Data Conversion, 151
- Accessing
 - C-200MT, 12
 - menu commands, 14
- Alignment
 - fabric, 33

B

- Bar Code Reader, 157
 - parameter, 139
- Beam Control Panel, 16
- Beam Square Test, 119
- Bite
 - 5 foot test diagnostic, 126
 - adjust values diagnostic, 111
 - display lines, 63
 - parameters, 152
 - pause between, 34
 - positioning first, 26
 - Run Time Biting, 67
 - search, 41
- Block Delete, 155
- Bristle Cleaner, 95
 - parameters, 147

C

- C-200MT
 - accessing, 12
 - closing, 22
 - main cutter control screen, 12
- C-axis
 - angle diagnostic, 109
 - parameters, 144, 153
 - sharpen speed, 160
- Calibration
 - conveyor/CTOT speed, 112
 - KI, 108
 - PI diagnostic, 129

- Center Line Origin, 34
 - parameters, 151, 156
- Change User Directory, 82
- Check Origin, 35
- CIDB, 84
 - parameters, 157–158
- Clipping Window, 34
 - parameters, 157
- Closing
 - C-200MT, 22
 - marker, 42
- Commands
 - accessing, 14
 - C-200B code chart, 201
- Concentric Circles, 118
- Contiguous Cut, 34
 - parameter, 159
- Continuous Cut, 34
 - parameter, 153
- Continuous Run, 111
- Conveyor
 - parameters, 153, 163
 - speed diagnostic, 112
- CTOT, 163
 - speed diagnostic, 112
- Cut File
 - See Marker
- Cut Tests
 - 10" Square, Center Drill Hole, 124
 - 5' Bite Test, 126
 - 50" Square Test, 117
 - Beam Square Test, 119
 - Concentric Circles, 118
 - Drill 1 Offset Setup, 127
 - Drill 2 Offset Setup, 128
 - Geometric Shapes, 125
 - Heel to Heel Test, 120
 - Knife Offset Setup, 127
 - Multiple 45 Degree Lines, 116
 - Multiple Horizontal Lines, 114
 - Multiple Vertical Lines, 115
 - Pen Offset Setup, 128

- Yaw in X Test, 122
 - Yaw in Y Test, 123
 - Cutter
 - initialize, 26
 - maintenance, 91–102
 - optimizing, 96
 - status mode, 20
 - turning on, 25
 - type parameters, 139
 - Cutter Info Data Base
 - See CIDB
 - Cutter Menu
 - Clipping Window, 34
 - Dry Run, 35
 - ESM, 102
 - Fabric Alignment, 33
 - Initialize, 26
 - Knife Settings, 98
 - Move Head To, 130
 - Move to Origin, 41
 - New Knife, 94
 - Null KI, 99
 - Origin, 31
 - Sharpen, 92
 - Start, 32
 - Vacuum, 30
 - Cutting
 - gauge, 19
 - parameters, 143
 - selecting speed, 32
 - Cutview, 60
 - colors, 61, 64
 - display bite lines, 63
 - display drill points, 63
 - display dry haul, 63
 - grid, 64
 - playback, 66
 - zoom, 62
- ## D
- Data Format, 83
 - parameters, 150
 - Data Scale Factor, 35
 - parameters, 150
 - Defaults
 - colors in Cutview, 61

- Queue Manager, 74
- user directory, 82
- Delete
 - parameters, 155–156
- Diagnostics, 103–130
 - 10" Square, Center Drill Hole, 124
 - 5' Bite Test, 126
 - 50" Square Test, 117
 - Beam Square Test, 119
 - C Axis Angle, 109
 - Concentric Circles, 118
 - Continuous Run, 111
 - Display Bite Adjust Values, 111
 - Drill 1 Offset Setup, 127
 - Drill 2 Offset Setup, 128
 - Geometric Shapes, 125, 127
 - Heel to Heel Test, 120
 - Input Output Test (DG23), 105
 - KI Calibration (DG20), 108
 - Knife Offset Setup, 127
 - Multiple 45 Degree Lines, 116
 - Multiple Horizontal Lines, 114
 - Multiple Vertical Lines, 115
 - Pen Offset Setup, 128
 - PI Calibration, 129
 - Position Info, 111
 - Servo I/O Test (DG16), 107
 - Single Step, 110
 - Watch Forces, 130
 - Yaw in X Test, 122
 - Yaw in Y Test, 123
- Diagnostics Menu, 104
 - Cut Tests, 112
 - Path Intelligence, 129
 - Software Diagnostics, 128
- Directory
 - change user, 82
 - manage, 80
- Drill
 - auxiliary (2) setup, 128
 - center hole diagnostic, 124
 - display points, 63

- main (1) offset setup, 127
- parameters, 140, 161
- preprocess, 35, 156
- Dry Haul
 - display in Cutview, 63
 - parameters, 147
- Dry Run, 35

E

- Enable Servo Power, 25
- Energy Savings Mode (ESM), 102
 - parameter, 145
- Error Messages, 165–188
 - class 1 FEP, 166
 - class 1 MCC, 174
 - class 2, 181
 - class 3, 185
 - class 4, 188

F

- Fabric Alignment, 33
- Feed Rate
 - parameters, 148
- Field Service, xiv
 - phone number, xiv, 165
- Fifty Inch (50") Square Test, 117
- File Manager, 77
- Five Foot (5') Bite Test, 126
- Forces
 - optimum parameter, 148
 - watch diagnostic, 130
- Frequently Used Parameters, 138
 - customize, 58

G

- Gauges, 18
- Geometric Shapes, 125
- Grid, 64

H

- Heel to Heel Test, 120
- Help, 15
- Home
 - See Initialize

I

- Icon Keys, 16
- Ignore Codes Parameters, 146
- Initialize
 - cutter, 26
- Input Codes, 195–198
- Input Output Test (DG23), 105
- Installing Software, 3–10
 - C-200MT, 6
 - creating icon, 9
 - cutters supported, 3
 - MCC software, 8
 - preparing for, 4
 - rebooting, 8
 - Windows NT, 4

K

- Keyboard
 - verify entry, 155
- KI Calibration (DG20), 108
- Knife
 - gauges, 18–19
 - new, 94
 - offset setup diagnostic, 127
 - parameters, 140, 149
 - Settings, 98
 - sharpen, 91
 - speed, 97
 - turn on motor, 32
- Knife Intelligence
 - gauge, 19
 - Knife Settings, 98
 - null, 99
 - parameters, 98, 147

L

- Language Support, 5
 - parameter, 154
- Laser
 - turning on, 31
- Lift & Plunge, 143
- Limit Switch Parameters, 161

M

- Main Cutter Control Screen
 - gauges, 18

- marker plot screen, 21
- menu bar, 13
- settings window, 21
- status bar, 21
- system messages box, 21
- system status window, 20
- tool bar, 16

Maintenance, 91

Marker

- advanced features, 33
- biting, 69
- check with Single Step, 110
- close, 42
- copy, 788
- delete, 80
- flip, 33
- mirror, 33
- move, 798
- open, 28
- processing, 32
- rename, 798
- reports, 84
- rerun, 29
- stacking, 33
- transfer, 156
- transfer for queue, 75
- view, 60

Marker Menu

- Change User Directory, 82
- Close, 42
- File Manager, 768
- Open, 28
- Rerun, 29

Mirroring, 33

- parameters, 157

Move Head To, 130

Move To Origin, 41

Multiple Line Diagnostic

- 45 degree, 116
- horizontal, 114
- vertical, 115

N

New Knife, 94

Null KI, 99

- after KI calibration, 108

O

Offset

- drill 1 diagnostic, 127
- drill 2 diagnostic, 128
- knife diagnostic, 127
- parameters, 160
- pen diagnostic, 128

OPSTOP, 35

- parameters, 158

Options and Modes

- Parameters, 154

Origin

- center line, 34
- check, 35, 155
- move to, 41
- restore, 40
- setting, 31

P

Parameter

- assigning access, 55
- changing, 52
- changing frequently used category, 58
- locking, 55
- searching for, 54

Parameter Category

- Bite Parameters, 152
- Bristle Cleaner, 147
- C-Axis, 153
- Conveyor and CTOT, 163
- Cutter Type, 139
- Cutting Parameters, 143
- Data Format/Scaling and RSO, 150
- Drill, 161
- Dry Haul Speeds, 147
- Frequently Used Parameters, 138
- Ignore Codes, 146
- Knife and Drill Speeds, 140

Knife and Path

- Intelligence, 147
- Limit Switches, 161
- Mirror Image and Clipping Window, 157

OPSTOP and Report

- Options, 158

Options and Modes, 154

PC Serial Communication, 139

Selvage Cut/Continuous Cut, 159

Servo (DSP) Coefficients, 163

Sharpen Parameters, 141

System Setup Parameters, 160

Time Considerations, 162

Vacuum System, 144

XY Axes, 153

Parameter Manager, 50

- advanced access, 55
- change setup, 53
- changing parameters, 52
- Print to File, 54
- search, 54
- working with, 52

Parameters, 137–164

- AAMA Data Conversion, 151

- Advance Before Plunge Distance, 143

- Advance Ignore Angle, 143

- Bar Code Reader Com Port, 139

- Bar Code Reader Option, 157

- Beam Width (1.7,2.0,2.4,shrt,lng), 139

- Bite Clip End Position, 152

- Bite Clip Start Position, 152

- Bite Overlap, 153

- Bite Park Minus, 153

- Bite Park Offset, 152

- Bite Vacuum Level, 145

- Bite Veeroff, 152

- Bite-Axis Stepsize, 163

- Block Delete, 155

- Bristl Cleanr

 - (0=N,1=motr,2=Pneum), 147

Bristle Cleaner Sweeps per Slat, 147
 C Axis Yaw Angle, 144
 C Axis Max Angle, 144
 C Home to System 0 Degrees, 160
 C Max Follow Error, 163
 C-Axis Acceleration, 153
 C-Axis cut velocity, 153
 C-Axis delay, 153
 C-Axis max velocity, 153
 C-axis Sharpen Speed, 160
 Center Line Calibration, 151
 Center Line Origin Center Point, 156
 Center Line Origin Edge Points, 156
 changing, 48
 Check Origin, 155
 Cleaner Head
 Retract/Plunge Time, 147
 Cleaner Head Sweep Time, 147
 Clipping High Boundary, 158
 Clipping High Boundary (Top Mark), 158
 Clipping Low Boundary, 158
 Clipping Low Boundary (Top Mark), 158
 Clipping Window Option, 158
 Contiguous Cut, 159
 Continuous Cut, 153
 Convey Last Bite Off Table, 152
 Conveyor Encoder (on Table) Step, 163
 Conveyor Encoder LOC (0=B,1=T), 163
 Conveyor Ramp Down Time, 163
 Conveyor Table Settle Time, 153
 Conveyor/CTOT Speed Calibrate, 112
 Corner Advance Distance, 143
 Corner Angle, 165
 Corner Overcut Distance, 143
 CTOT–Stop Distance, 163
 CTOT2–Start Delay, 163
 CTOT2–Stop Distance, 163
 Cut Distance Limit, 141
 Cut Speed=Maximum Knife Speed, 140
 Cut/Maximum Knife Speed, 140
 Cut/Plot Mode, 155
 Cutter Info Database Option, 157
 Cutter Info Database Output, 158
 Data Format, 151
 Data Logging Mask, 164
 Del Job from Queue after Cutting, 156
 Del Queue After Cutting, 156
 Delete Cut File After Cutting, 155
 Disallow Cutting with KI Off, 148
 Drill Idle Time Before Shutoff, 161
 Drill on only while selected, 161
 Dry Haul x Acceleration, 147
 Dry Haul y Acceleration, 147
 Dry Haul/Minimum Knife Speed, 140
 Dry Run, 155
 Energy Savings Mode, 145
 Event Logging, 164
 Heavy Duty Drill, 140
 Idle Knife Speed, 140
 Ignore Auto Origin (M70) Codes, 146
 Ignore Aux Drill (M44) Codes, 146
 Ignore Display Msg (M20) Codes, 146
 Ignore Feedrate (F) Codes, 146
 Ignore Label Cycle (M31) Codes, 146
 Ignore Lift & Plunge (M46) Codes, 146
 Ignore Main Drill (M43) Codes, 146
 Ignore Move Conveyor (M69) Codes, 146
 Ignore OV, AP Off (M19) Codes, 146
 Ignore Overcut Off (M18) Codes, 146
 Ignore Pen (D1+D2) Codes, 146
 Ignore Sharpen (M42) Codes, 146
 Ignore Slow Down Codes, 146
 Insert M23 Edge Clip Code, 152
 Intermarker Gap, 159
 KI Option, 148
 KI Spring Factor, 147
 KI: Corner Disable Time, 148
 KI: Deflection Angle, 98, 147
 KI: Error Detection, 147
 KI: Fail Time, 148
 KI: Gain, 98, 147
 KI: Max Turn Angle, 147
 KI: On/Off, 147
 Knife Break Force, 149
 Knife Break Risk Point, 149
 Knife Spd Sensor: Volts per KRPM, 140
 Knife Speed Checking, 140
 Knife Wear Limit, 142
 Knife Wear Type, 142
 Language Support, 154
 Length of Reverse Segment, 165
 Lift & Plunge Corner Angle, 143
 Lm Switch Status–Bite Sensor, 161
 Lm Switch Status–Drill 1, 161
 Lm Switch Status–Drill 2, 161

Lm Switch Status–Knife, 161
 Lm Switch Status–Pen, 161
 Lm Switch Status–Sharpen Arm, 161
 M17 (0 Heel Cut) Advance, 143
 M19 (Slit Notch) Advance, 143
 M25 Slowdown Percentage, 143
 Marker End Park (0=None, 1=-Y, 2=+Y), 152
 Marker End Park Position X, 153
 Marker End Park Position Y, 153
 Marker Flip, 154
 Marker Flip Top, 154
 Marker Size: Use Auto Calculate, 29, 151
 Marker Size: Use M20 Code, 151
 Marker Stacking Reorder, 154
 Marker Stacking Reorder Channel, 154
 Max Allowable Conveyor Friction, 163
 Max Cut Acceleration, 160
 Max Distance with Knife Down, 165
 Max time for Auto Bite, 162
 Max time: Idle in ManBite Mode, 162
 Max time: Idle in TrimCut Mode, 162
 Max time: To move down–bite sns, 162
 Max time: To move down–drill 1, 162
 Max time: To move down–knife, 162
 Max time: To move down–pen, 162
 Max time: To move up–bite sns, 162
 Max time: To move up–drill 1, 162
 Max time: To move up–knife, 162
 Max time: To move up–pen, 162
 Max time: To turn off–drill, 162
 Max time: To turn on–drives, 162
 Max time: To turn on–vacuum, 162
 Max time: Up to speed–drill 1, 162
 Max time: Up to speed–knife, 162
 Max time: Vacuum Drop, 162
 Maximum Bite Adjustment, 153
 Maximum Bite Length, 152
 Maximum Cut Velocity, 160
 Maximum Segment Length, 143
 MCC Communications Port, 139
 Metric Display, 155
 Milliseconds between samples, 164
 Minimum Bite Length, 152
 Minimum Size of First Bite, 159
 Minimum Web Cut Size, 159
 Mirror Image, 157
 Mirroring Option, 157
 Num of Vac Zones Closed for Bite, 145
 Num sharpens until angle adjust, 142
 Number of Sharpen Cycles, 142
 Number of Sides to Sharpen, 141
 Number of Table Slats, 147
 Number of Vacuum Zones, 145
 Offset in X–Drill 1, 160
 Offset in X–Drill 2, 160
 Offset in X–Knife, 160
 Offset in X–Pen, 160
 Offset in Y–Drill 1, 160
 Offset in Y–Drill 2, 160
 Offset in Y–Knife, 160
 Offset in Y–Pen, 160
 One-Way Bristle Cleaning, 147
 OPSTOP, 158
 Overcut Distance, 143
 Path Intelligence Option, 148
 Pause Before Convey, 152
 Pause Between Bites, 152
 Pause Between Queue Manager Jobs, 159
 PI: Feedrate: Change Ratio, 148
 PI: Feedrate: Max Increase, 148
 PI: Feedrate: Maximum, 148
 PI: Feedrate: Minimum, 148
 PI: Force to Stop with Warning, 149
 PI: FR Control–XY Force, 148
 PI: FR Faster–Shp Knife, 148
 PI: FR Slowdown–Low Vac, 148
 PI: Optimum Force, 148
 PI: Sharp Knife Full Speedup Dst, 149
 PI: Sharp Knife Prtl Speedup Dst, 149
 PI: Sharp Knife Speedup Amount, 149
 PI: Vacuum Low Slowdown Factor, 149
 PI: Velocity to +FR, 149
 PI: Velocity to +FR & Rbld, 149
 PI: Velocity to -FR, 149
 PI: Velocity to -FR & Rbld, 149
 Plaid/Stripe Matching System, 139
 Preprocess Drills, 156
 Preset OPSTOP, 158
 Ramp Down Dist–Auto Bite, 160

Re-Sealer Option, 155
Regional OPSTOP, 158
Resealer Up for
 Continuous Cut, 156
Right Side Control, 139
Right Side Initialize, 151
Run Time Biting, 152
Selv/Web
 (0=Off,1=Selv,2=Web&
 Sel), 159
Selvage Cut Position, 159
Selvage Cut Size, 159
Sharpen Every n Pieces,
 142
Sharpen Frequency, 141
Sharpen Knife Speed, 140
Sharpen New Knife n
 Times, 142
Sharpen Only When Knife
 is Up, 142
Sharpen Position #1, 141
Sharpen Position #2, 141
Sharpening Time, 141
Sharpens Until Overcut
 Update, 142
Single Step, 154
Slat Advance Time, 147
Table Length
 (0=Strd,1=Long), 139
Time Until ESM, 145
TONT–Start Delay, 163
TONT–Stop Distance, 163
Transfer Markers When
 Selected, 156
Usable Table Distance in
 X, 160
Usable Table Distance in
 Y, 160
Vacuum Control–Pattern
 Length, 145
Vacuum Control–Vacuum
 Gain, 145
Vacuum Control–Zero
 Offset, 145
Vacuum Error Reporting,
 144
Vacuum Level–Bite, 144
Vacuum Level–Cut, 144
Vacuum Level–Idle, 144
Vacuum Level Control,
 144

Vacuum Level Valve on
 Inlet, 145
Vacuum Low Caution
 Level, 145
Vacuum Low Error Level,
 145
Vacuum Zone Overlap,
 144
Vacuum Zoning, 144
Variable Length Biting,
 152
Variable Speed CTOT, 163
Velocity–Cnvyr Auto Bite,
 163
Velocity–Cnvyr Cut Bite,
 163
Velocity–Cnvyr Jog, 163
Velocity–Cnvyr Man Bite,
 163
Verify Keyboard Entry,
 155
X Data Scale Factor, 150
X Home to System 0, 153
X Home Zone 1 Offset,
 144
X Maximum Dry Haul
 Velocity, 147
X-Axis Stepsize, 160
Y Axis Edge Alignment,
 157
Y Data Scale Factor, 150
Y Home to System 0, 153
Y Maximum Dry Haul
 Velocity, 147
Y-Axis Mirror Image, 158
Y-Axis Mirror Reflection
 Line, 158
Y-Axis Stepsize, 160
Path Intelligence, 101
 diagnostic, 126
 force diagnostic, 130
 parameters, 147
Paths, 788
PC Serial Communication
 Parameters, 139
Pen Offset Setup, 128
Piece
 recut, 40
 search, 39
Plaid/Stripe Matching, 139
Playback, 66

Pointing Device, 189
Position Info, 111
Print
 CIDB output file, 88
 setup, 54

Q

Queue, 69
 close, 72
 create, 708
 delete job after cutting, 156
 delete parameters, 156
 edit, 73
 run, 72
 select next job, 72
Queue Manager, 708
 defaults, 74
 pause between jobs, 159
Quit Menu, 22

R

Recover Menu
 Bite Search, 41
 Piece Recut, 40
 Piece Search, 39
 Restore Origin, 40
 Restore State, 37
Recovery, 36
Reports
 See also CIDB
 CIDB parameter, 158
 in C-200MT program, 86
 in database program, 89
 marker, 84
 output to file, 87
 setup for, 85
Resealer
 parameters, 155–156
Restore Origin, 40
Restore State, 37
 manually, 38
RSO, 139
 initialize, 26, 151
 marker size, 29
Run Time Biting, 67
 parameters, 152
 static length, 67
 variable length, 68

S

- Search
 - parameters, 54
- Selvage Cut Parameters, 159
- Servo I/O Test (DG16), 107
- Settings, 27, 44
- Setup Menu, 43
 - Parameter Manager, 50, 52
 - Settings, 44–45, 47, 49
- Setups, 43
 - preset, 27, 46
 - print, 54
 - select/change in Parameter Manager, 53
 - selecting, 27, 45
- Sharpen, 92
 - parameters, 92, 141
- Shutdown
 - Windows NT, 22
- Single Step, 110
 - parameter, 154
- Software
 - See Installing Software
 - parameters, 164
- Software Diagnostics
 - Debug Window, 128
 - Restorable Info, 128
 - Servo Data Logging, 128
- Speed
 - gauges, 18
 - knife, 97
 - parameters, 140
- Support
 - customer, xiv
 - phone number, xiv
- System Parameters
 - setup, 160

T

- Table
 - parameters, 139, 147, 160
- Ten Inch (10") Square,
 - Center
- Drill Hole, 124
- Time Considerations
 - Parameters, 162
- TONT, 163
- Trim Cut, 32

U

- Utilities
 - Cidb Reports, 86
- Utilities Menu
 - Bristle Cleaner, 95
 - Cidb Reports, 84
 - Queue Manager, 69
 - View Marker, 61

V

- Vacuum
 - ESM, 102
 - level gauge, 18
 - parameters, 102, 144
 - turning on, 30
- Velocity
 - parameters, 149
- View Marker
 - See Cutview

W

- Wildcards, 788
- Window
 - clipping, 34
- Windows Basics, 189–194

X

- X Data Scale Factor, 35, 150
- XY Axes Parameters, 153
- XY-Axes Delay, 153
- Y
 - Y Data Scale Factor, 35, 150
- Yaw
 - c-axis angle parameter, 144
- Yaw in X Test, 122
- Yaw in Y Test, 123

